



In Touch Refinishing Polishing Instruction



1. SAND WET SURFACE WITH 2000 GRIT WET OR DRY SANDPAPER. BE SURE TO USE PLENTY OF WATER.
2. DRY OFF THE SURFACE AND APPLY EXTRA CUT RUBBING COMPOUND.
3. APPLY COMPOUND IN CIRCULAR MOTIONS UNTIL YOU SEE A SHINE APPEAR. CHECK THE SHINE AND RE-APPLY COMPOUND AS NEEDED.
4. BUFF THE SURFACE USING A LOW SPEED POLISHER.

